





The MimioCapture™ ink recording system works seamlessly with the MimioTeach™ interactive system to capture dry erase whiteboard notes in real time.



Expo® dry erase markers insert directly into MimioCapture styli.



The ergonomically designed markers and erasers recharge quickly on the charging tray.



Status Lights

Off: The MimioCapture pen or eraser is not receiving power. The battery needs to be recharged.

Solid Amber: The MimioCapture pen or eraser has a low battery. The battery should be recharged.

Solid Green: The MimioCapture pen or eraser is in the tray and charging.